

6658202




Fig. 1




Fig.3

FIRMWARE FLOW DIAGRAM MAIN SYSTEM OPERATION




Fig. 4

00149443-090998

COPY OPERATION DATA FROM MODULE TO MASS STORAGE




Fig. 5A




Fig. 5D

ERASE OPERATION ERASE DATA FROM MODULE




Fig. 5B

355060" 34464760

COMPUTER INTERFACE COMMAND UPLOAD / DOWNLOAD DATA, AND REMOTE CONTROL




Fig. 5C

00149443-090993